

ST-3 XT3

TRANSFORMER RATED
WIRELESS SITE TESTER

Connection Guidelines



ST-3/XT3 Connection Guidelines



It is essential that the User Guide be read thoroughly before putting this product into service.

Installing the ST-3/XT3

Follow the procedure described in the *Installation of the ST-3/XT3* section from its User Guide.

REMINDER: Make sure to configure the removable twist tabs and that the form selector switch is set up according to the meter base form you are testing.

Insert the ST-3/XT3 to the meter base and turn on the device using the ON/OFF switch.

Connecting to the ST-3/XT3 with a mobile device



1 To connect, start the **Probewell Connect** application on your mobile device.



2 Scan QR code on the device for a first use.

Minimum system requirements: iOS 11 or Android 7.

Download the
Probewell Connect
mobile application



Connecting to the ST-3/XT3 with a computer



1 To connect, go to Windows Settings, select **Network & Internet**.

A Click on **Show available networks**
(**Tip:** shortcut often located on the bottom right of your screen)

B Scroll down at the end of the list, select **Hidden Network** or **Other Network**

C Input the socket SSID located below the QR code and click **Next** (i.e., **PW-XT3-[S/N]-AP**).

B

C

A



2 Start the **Probewell Connect*** application from your computer.

*To download and install the Probewell Connect app for Windows, visit: www.probewell.com/pw-connect (Minimum system requirement: Windows 10)

Note: Once the procedure is completed, the SSID will remain available directly from the network list menu in the **known networks** on Windows.

Note: The device only allows one user to connect at a time.

Version 1.0